



Comments:

- > C905 eliminated (Absorbed by C900 in 2016)
- > Riber Sewer variants merged in single Trade name
- > "Classic Rieber" changed to "Riber IPS"

## PVC

Trade Name	AWWA		UL	ASTM				PBS	QWS	SCS	
	C900	C909	651	D2241	D3034	F679	F1483	F512	PTS77	CAO8546	430-DD
Super Rieber	✓										
One-Piece	✓	✓									
Mambo	✓	✓									
Turner	✓	✓									
K2 Spline Lock	✓		✓	✓							
Rieber IPS				✓							
Hero Rieber				✓							
Mambo IPS				✓							
Turner IPS				✓			✓				
Rieber Sewer					✓	✓					
Mambo Sewer					✓						
PRR Sewer					✓						
One-Piece							✓				
Mambo							✓				
Turner							✓				
SR Duct								✓			
SR C-Duct								✓	✓		
Platinum PIP											✓

## Ductile Iron

Trade Name	AWWA C111 /A21
Fasttite	✓
Mechanical Joint (MJ)	✓
Push-on	✓
Transition (CIOD - IPS)	✓

## Corrugated

Trade Name	ASTM		
	F794	F667	F2763
Lotus / Summit	✓	✓	✓